

Replacing a SeeSnake Camera Head



Introduction

This guide explains how to remove and install the camera head on a SeeSnake camera reel. Removing the camera head may be needed for service, troubleshooting, or to inspect components inside the spring.

Contents

Removing the Camera Head	Page 3
Installing the Camera Head	Page 5

Tools & Materials Needed

- SeeSnake Spanner Wrench

Safety Symbols

NOTICE

NOTICE indicates information that relates to the protection of property.

Removing the Camera Head


Step 1

Snap the spanner wrench onto the spring, just behind the camera.



Step 2

Align the notch inside the spanner wrench with the end of the spring coil.



Step 3

Unscrew the spring from the camera.




Step 4

Loosen the locking sleeve with a pair of pliers.



Step 5

Unthread the locking sleeve from the camera.




Step 6

Pull the camera straight out of the sonde's socket.

NOTICE

To avoid damaging the camera's connector pins, do not bend or twist while pulling the camera out of the connector.



Installing the Camera Head

Step 1

Align the camera head pins with the sonde's socket and push together.



Step 2

Thread the locking sleeve onto the camera and tighten by hand.



Step 3

Make sure the safety cables are straight when you screw the camera onto the spring. In order to do so, backwind the camera 2 turns (counter-clockwise).



Step 4

Thread the spring onto the camera until the end of the spring is flush against the camera head.

NOTICE

Do not over-tighten the spring.



SeeSnake Factory Service

Repair:

+1 (858) 244-6689

Product Support:

+1 (888) 477-5339

3777 Ruffin Road
San Diego, CA 92123-1813